



## 5. Visitor & Intercom System Instructions

1. When a visitor calls a resident on the intercom system from Toorak Road entry gate (primary entrance) and lobby doors (secondary entrance), they have to dial 1 or 2 and apartment number on the code pad. The number prefix 1 or 2 in front of the apartment number indicates that the apartment is in Low Rise Tower – 227 Toorak Road (1) or High Rise Tower – 229 Toorak Road (2).
2. Visitors have to dial 1 or 2 and apartment number then the OK key call on the entry station code pad and it will start ringing. Example for apartment 101 on Level 1 Low Rise Tower, visitor has to dial “1101”. Apartment 101 on High Rise Tower, visitor has to dial “2101”.
3. The apartment intercom unit sounds a tone and the resident can answer by pressing the call button on the unit. Two-way communication takes place between the called intercom unit and the hands-free external entry station.
4. If the caller is to be admitted, the resident presses the key button on the intercom unit, and the door/gate will be released whilst simultaneously releasing the security at the lift so the lift car can travel to the floor of the called apartment within a pre-set time.
5. There is a separate entrance for Low Rise Tower (227 Toorak Road) and High Rise Tower (229 Toorak Road). 227 and 229 numbers are located in the lobby entrance of each tower.
6. There are no visitor parking spaces available at ILK South Yarra. There is public car parking available on Daly Street and Chapel Street.
7. Please refer to Operating Instructions for Bticino Audio/Video Intercom System under Section 10 of this manual.